Selecting presets in the unit itself

It is possible to select stored presets in the DSP unit, directly from the AVIATOR S 115 A amplifier. To do this, follow the following steps:

1. Connect the system to the mains and put the switch button in ON position.



2. Move the preset selector to select the desired preset.



The factory presets included are the following:

- Preset nº1: to combine AVIATOR S 115 A with AVIATOR 115 A. Frequency cutt-off applied to AVIATOR S 115 A; 100 Hz.
- Preset nº2: to combine AVIATOR S 115 A with AVIATOR 115 A. Frequency cutt-off applied to AVIATOR S 115 A; 125 Hz.
- Preset nº3: to combine AVIATOR S 115 A with AVIATOR 112 A. Frequency cutt-off applied to AVIATOR S 115 A; 100 Hz.
- Preset nº4: to combine AVIATOR S 115 A with AVIATOR 112 A. Frequency cutt-off applied to AVIATOR S 115 A; 125 Hz.
- Preset nº5: to combine AVIATOR S 115 A with AVIATOR i 804. Frequency cutt-off applied to AVIATOR S 115 S; 150 Hz.



If you have any technical problem or questions about Pro DG Systems products; contact our technical support department at: sat@prodgsystems.com