


Selecting presets in the unit itself

It is possible to select stored presets in the DSP unit, directly from the AVIATOR S 118 A amplifier. To do this, follow the following steps:

1. Connect the system to the mains and put the switch button in ON position



2. Move the preset selector to select the desired preset.



PRESETS	
1	AVIATOR 115A-90Hz
2	AVIATOR 115A-120Hz
3	AVIATOR 112A-90Hz
4	AVIATOR 112A-120Hz
5	LA-2X10 A 90Hz

The factory presets included are the following:

- Preset nº1: to combine AVIATOR S 118 A with AVIATOR 115 A. Frequency cutt-off applied to AVIATOR S 118 A; 90 Hz.
- Preset nº2: to combine AVIATOR S 118 A with AVIATOR 115 A. Frequency cutt-off applied to AVIATOR S 118 A; 120 Hz.
- Preset nº3: to combine AVIATOR S 118 A with AVIATOR 112 A. Frequency cutt-off applied to AVIATOR S 118 A; 90 Hz.
- Preset nº4: to combine AVIATOR S 118 A with AVIATOR 112 A. Frequency cutt-off applied to AVIATOR S 118 A; 120 Hz.
- Preset nº5: to combine AVIATOR S 118 A with AVIATOR LA 210. Frequency cutt-off applied to AVIATOR S 118 S; 90 Hz.



If you have any technical problem or questions about Pro DG Systems products; contact our technical support department at: sat@prodgsystems.com